

PERRY ISLAND SPB (PYL) O S UTC-9(-8DT) N60°41.12' W147°55.12'

ANCHORAGE

00 NOTAM FILE JNU

WATERWAY N-S: 10000X2000 (WATER)**COMMUNICATIONS:** CTAF 122.9**RADIO AIDS TO NAVIGATION:** NOTAM FILE JNU.**JOHNSTONE POINT (VH) (H) VORW/DME** 116.7 JOH Chan 114 N60°28.86' W146°35.96' 270° 40.9 NM to fld.
48/18E.

wx cam

VOR unusable:

006°-050° byd 40 NM

061°-072° byd 40 NM

090°-124° byd 23 NM blo 8,000'

125°-188° byd 10 NM

189°-194° byd 40 NM blo 6,000'

189°-194° byd 58 NM

202°-209° byd 40 NM

324°-329° byd 40 NM

355°-005° byd 40 NM blo 14,000'

355°-005° byd 53 NM

DME unusable:

090°-124° byd 23 NM blo 12,000'

125°-191° byd 10 NM

PERRYVILLE (PEV)(PAPE) 1 SSW UTC-9(-8DT) N55°54.40' W159°09.65'

COLD BAY

30 B NOTAM FILE ENA

L-2K

RWY 02-20: 3300X75 (GRVL) MIRL

IAP

RWY 02: REIL. PAPI(P4L)—GA 3.4° TCH 28'. Brush.**RWY 20:** Brush.**SERVICE:** LGT ACTVT REIL Rwy 02; PAPI Rwy 02; MIRL Rwy 02-20
and rotating bcn—CTAF.**AIRPORT REMARKS:** Unattended. Rwy cond unmnt; rcmd visual insp bfr
use. Rwy 02-20 ruts.**AIRPORT MANAGER:** 907-246-3325**WEATHER DATA SOURCES:** AWOS-3P 118.1 (907) 269-2843. (WX CAM)**COMMUNICATIONS:** CTAF 122.9⑧ **ANCHORAGE CENTER APP/DEP CON** 125.35**RADIO AIDS TO NAVIGATION:** NOTAM FILE SDP.**BORLAND NDB/DME (HW)** 390 HBT Chan 79 N55°18.94'

W160°31.10' 041° 58.3 NM to fld. 130/11E.

NDB unusable:

304°-354° byd 16NM

DME unusable:

034°-134° byd 6NM

184°-264° byd 27 NM blo 14,000'

184°-264° byd 6 NM blo 10,000'

354°-034° byd 22 NM blo 18,000'

354°-034° byd 27NM

354°-034° byd 6 NM blo 10,000'

COMM/NAV/WEATHER REMARKS: For a local call to Cold Bay FSS dial 1-800-478-7250. For a toll free call to Kenai FSS dial 1-866-864-1737.