

## CONTINUED FROM PRECEDING PAGE

**RADIO AIDS TO NAVIGATION:** NOTAM FILE SIT.

**LEVEL ISLAND (H) VORW/DME** 116.5 LVD Chan 112 N56°28.06' W133°04.99' 160° 53.4 NM to fld. 98/20E.

VOR unusable:

038°-098° byd 35 NM blo 9,000'

098°-138° byd 25 NM blo 7,000'

168°-208° byd 35 NM blo 6,000'

268°-328° byd 25 NM blo 9,000'

328°-358° byd 30 NM blo 7,000'

328°-358° byd 35 NM blo 8,000'

358°-038° byd 35 NM blo 12,000'

wx cam

DME unusable:

038°-098° byd 35 NM blo 9,000'

098°-138° byd 25 NM blo 7,000'

168°-208° byd 35 NM blo 6,000'

268°-328° byd 25 NM blo 9,000'

328°-358° byd 30 NM blo 7,000'

328°-358° byd 35 NM blo 8,000'

358°-038° byd 35 NM blo 12,000'

**NDB/DME (HW)** 229 AKW Chan 105 N55°34.12' W133°04.88' at fld. 30/20E. NOTAM FILE AKW.

NDB/DME unusable:

034°-189° blo 8,000'

304°-354° blo 8,000'

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Ketchikan FSS dial 800-478-3500. For a LC to Juneau FSS dial 789-7380.

**KOBUK** (OBU)(PAOB) 0 N UTC-9(-8DT) N66°54.74' W156°53.84'

142 B NOTAM FILE OTZ

**RWY 09-27:** 4020X75 (GRVL) MIRL

**RWY 09:** Brush.

**RWY 27:** Brush.

**SERVICE:** LGT ACTIVATE MIRL Rwy 09-27—CTAF.

**AIRPORT REMARKS:** Unattended. Rwy condition not monitored, recommend visual inspection prior to ldg. Float plane opr on lake. Dip on Rwy 09 abeam slough. Parallel p-line north of rwy.

**AIRPORT MANAGER:** 907-442-3147

**COMMUNICATIONS:** CTAF 122.7

**AMBLER RCO** 122.0 (KOTZEBUE RADIO)

Ⓡ **ANCHORAGE CENTER APP/DEP CON** 119.2

**RADIO AIDS TO NAVIGATION:** NOTAM FILE OTZ.

**KOTZEBUE (H) VORW/DME** 115.7 OTZ Chan 104 N66°53.14'

W162°32.40' 072° 133.4 NM to fld. 121/15E.

**AMBLER NDB (HW)** 403 AMF N67°06.31'

W157°51.61' 102° 25.5 NM to fld. 258/15E. NOTAM FILE

AFM.

**COMM/NAV/WEATHER REMARKS:** For LC to Kotzebue FSS dial 907-442-3310.

For a toll free call to Kotzebue FSS dial 1-800-478-7460. For a toll free call to Fairbanks FSS dial 1-866-248-6516.

**FAIRBANKS**

H-2A, L-4I

IAP

