

**TRIPOD** (Z25) 2 SE UTC-9(-8DT) N59°15.79' W158°33.47'  
225 NOTAM FILE DLG

KODIAK

**RWY 11-29:** 1250X50 (TURF-GRVL)

**RWY 11:** Trees.

**RWY 29:** Trees.

**RWY 18-36:** 850X40 (GRVL-DIRT)

**RWY 18:** Trees.

**RWY 36:** Trees.

**AIRPORT REMARKS:** Unatndd. Rws not maintained; recommend prior inspection before use. Rwy 18-36 has 7' trees growing in the center of the rwy midfield. Rwy unusable for fixed wing acft. Rwy 11 forest with 32' trees 0' from threshold. Rwy 36 forest across entire apch up to 0' of threshold. No rwy markings either rwy. Rwy 11-29 sfc consists of a narrow ATV trail and undulating tundra which slopes downhill towards north. Rwy 18-36 unusable only 10 ft wide with 6-12 ft trees encroaching & rocks to 10 inches on sfc. Rwy 18-36 used as an ATV camping site.

**COMMUNICATIONS:** CTAF 122.9

**ALITAK SPB** (See LAZY BAY on page 166)

**ALL WEST** (See DELTA JUNCTION on page 93)

**ALLAKAKET** (6A8)(PFAL) 1 SSE UTC-9(-8DT) N66°33.11' W152°37.33'  
441 B NOTAM FILE FAI

FAIRBANKS

H-1A, L-4I

**RWY 05-23:** 4000X100 (GRVL) MIRL

IAP

**RWY 05:** Brush.

**SERVICE:** LGT ACTIVATE MIRL Rwy 05-23—CTAF.

**AIRPORT REMARKS:** Unattended. Rwy condition not monitored, recommend visual inspection prior to landing. Snow removal ops during winter, monitor CTAF. Cold temperature restricted airport. Altitude correction required at or below -44C. Rwy 05-23 NSTD markings, marked with lgts and cones. Rot bcn may not be observed from northern quadrants at low altitudes.

**AIRPORT MANAGER:** (907) 451-5280

**COMMUNICATIONS:** CTAF 122.9

**BETTLES RCO** 122.2 (FAIRBANKS RADIO)

**ANCHORAGE CENTER APP/DEP CON** 124.6

**RADIO AIDS TO NAVIGATION:** NOTAM FILE BTT.

**BETTLES (H) VORW/DME** 116.0 BTT Chan 107 N66°54.30'  
W151°32.15' 211° 33.5 NM to fld. 637/20E.

VOR AZIMUTH & DME unusable:

047°-077° byd 24 NM

**COMM/NAV/WEATHER REMARKS:** For a toll free call to Fairbanks FSS dial 1-866-248-6516.

