


---

## MANASSAS REGIONAL AIRPORT (HEF)

---

### Landing South RWY 16L and RWY 16R




**Pilots sometimes confuse RWY 16L and  
RWY 16R due to proximity of  
runway thresholds.**

**Not for Navigational Purposes  
For Situational Awareness Only**

# MANASSAS REGIONAL AIRPORT (HEF)

---

## Landing North RWY 34R and RWY 34L



**Pilots sometimes confuse RWY 34R and  
RWY 34L due to proximity of runway thresholds.**

**Not for Navigational Purposes  
For Situational Awareness Only**