

MANASSAS REGIONAL AIRPORT (HEF)

Landing South RWY 16L and RWY 16R




**Pilots sometimes confuse RWY 16L and
RWY 16R due to proximity of
runway thresholds.**

**Not for Navigational Purposes
For Situational Awareness Only**

MANASSAS REGIONAL AIRPORT (HEF)

Landing North RWY 34R and RWY 34L



**Pilots sometimes confuse RWY 34R and
RWY 34L due to proximity of runway thresholds.**

**Not for Navigational Purposes
For Situational Awareness Only**