

DANIEL K INOUE INTL (HNL) ARRIVAL ALERT

Landing Northeast RWY 4L and RWY 4R



Pilot sometimes confuse RWY 4L and RWY 4R.

**Not for Navigational Purposes
For Situational Awareness Only**

HONOLULU (DANIEL K INOUEY INTL) AIRPORT HNL RUNWAY INCURSION AND WRONG SURFACE LANDING RISKS

Runways 04–22 Runway Incursion Risk: The runway holding position markings (hold lines) between Runway 04L–22R and Runway 04R–22L are relocated, with minimal space of approximately 20 feet between them. Pilots are reminded to hold short of the parallel runway until a clearance is received to cross that runway. ATC is aware that the aircraft tail may not be clear of the exiting runway and is restricting arriving and departing aircraft on that runway.

For additional information, enter this link into your web browser to view a short video on FAA's You Tube Channel: <https://youtu.be/OzwZvJPcGIs>.

Wrong Surface Landing Risk: Rwy 04R/Rwy 04L thresholds. Pilot expectation bias or runway confusion cause a potential for wrong runway landings. Pilots are reminded to acknowledge landing runway assignment and visually confirm lined up for the correct runway.

For additional information contact Honolulu Control Facility (HCF) at 808-840-6100.

LASER LIGHT OPERATION

Keck Observatory, Gemini Observatory and Subaru Observatory

A permanent laser light operation is being conducted nightly between sunset and sunrise at Keck Observatory and Gemini Observatory N19–49–26/W155–28–09, Kamuela VOR (MUE) 122 degree radial at 16 nautical miles. The laser beam may be injurious to eyes if viewed on axis. Cockpit illumination and flash blindness may also occur if the beam enters the cockpit. Honolulu Control Facility, (808) 840–6201 is the FAA coordination facility.

Maui Space Surveillance Complex

A permanent laser light operation is being conducted nightly between sunset and sunrise at the Maui Space Surveillance Complex (MSSC) N204231/W1561528, Maui VOR (OGG) 131 degree radial at 15 nautical miles. The laser beam may be injurious to eyes if viewed on axis. Cockpit illumination and flash blindness may also occur if the beam enters the cockpit. Honolulu Control Facility, (808) 840–6201 is the FAA coordination facility.
