

KOTZEBUE

RALPH WIEN MEML (OTZ)(PAOT) 1 S UTC-9(-8DT) N66°53.09' W162°35.89'

15 B ARFF Index—See Remarks NOTAM FILE OTZ

RWY 09-27: H6300X150 (ASPH-GRVD) S-100, D-128, 2S-162,
2D-240 PCN 91 F/B/X/T HIRL

RWY 09: REIL. PAPI(P4R)—GA 3.0° TCH 43'. RVR-T Thld dsplcd
400'. Road.

RWY 27: REIL. PAPI(P4L)—GA 3.3° TCH 46'. RVR-R Hill.

RWY 18-36: 3876X90 (GRVL-NONE) MIRL

RWY 18: Road.

RUNWAY DECLARED DISTANCE INFORMATION

RWY 09: TORA-6300 TODA-6300 ASDA-6300 LDA-5900

RWY 27: TORA-5900 TODA-5900 ASDA-5900 LDA-5900

SERVICE: S2 FUEL 100, JET A LGT HIRL Rwy 09-27 and MIRL Rwy
18-36 ops 1600-0900Z† other hrs ACTIVATE—CTAF. ACTIVATE
REIL Rwy 09 and Rwy 27—CTAF. PAPI Rwy 09 and Rwy 27 opr
continuously.

AIRPORT REMARKS: Attended Wed-Mon 1500-0500Z†, Tue 1500-0600Z†.

Arpt maint dty hrs 1600-0500Z† daily. Class I, ARFF Index B. ARFF
svc avbl during periods of air carrier ops only. CLOSED to air carrier ops
with more than 30 passenger seats except PPR in writing, to arpt mgr,
Box 55, Kotzebue, AK 99752. Rwy 18-36 not avbl for scheduled or
unscheduled acr ops with more than 30 psgr seats. Rwy 18-36 acft
ops greater than 49' wingspan approved with PPR fr arpt mgr. Uncontrolled
vehicle access to Rwy 18-36. Parking area not lighted. No storage. Road 30'
from thld Rwy 09. Large flocks of migratory birds in vicinity during season.
Snow removal, wildlife control, cond reporting, and other airfield maint
services only avbl and valid during arpt maint duty hrs. Ctc arpt mgmt
for any after-hours req for airfield services. Uncontrolled vehicle access
to Rwy 18-36. Rwy lghts 09-27 and 18-36 extend 30 inches above
ground. Twys and ramps have numerous dips and rough surfaces. Numerous
wind turbine twrs 395' (330 AGL) approximately 3.5 miles SE of the arpt.
No locked wheel turns on Rwy 09-27 surface. Ravens invof arpt year
round. Transient acft parking located on west side of Twy F. Arpt sand
larger gradation than FAA recommended/see AC150/5200-30. TSA
regulated airport. See 49 CFR 1542. All gates and doors must be secured
at all times. Transient or unfamiliar pilots contact airport manager with
questions.

AIRPORT MANAGER: 907-442-3147

WEATHER DATA SOURCES: ASOS 135.45 (907) 442-2279. (WX CAM)

COMMUNICATIONS: CTAF 123.6 AFIS 135.45 UNICOM 122.8

FSS OTZ (KOTZEBUE) 1600-0900Z†; OT ctc Fairbanks FSS.

KOTZEBUE RADIO 120.3 121.5 122.2 123.6 (LAA 123.6)

ANCHORAGE CENTER APP/DEP CON 119.2 263.0

AIRSPACE: CLASS E svc continuous.

RADIO AIDS TO NAVIGATION: NOTAM FILE OTZ.

KOTZEBUE (H) VORW/DME 115.7 OTZ Chan 104 N66°53.14' W162°32.40' 253° 1.4 NM to fld. 121/15E.

HOTHAM NDB (HW) 356 HHM N66°54.08' W162°33.86' 208° 1.3 NM to fld. 11/11E.

ILS/DME 110.7 I-OTZ Chan 44 Rwy 09.

COMM/NAV/WEATHER REMARKS: For local call to Kotzebue FSS dial 907-442-3310. For a toll free call to Kotzebue FSS dial 1-800-478-7460. For a toll free call to Fairbanks FSS dial 1-866-248-6516. WSO telephone 442-3231. AFIS opr by Kotzebue FSS when open.

NOME
H-1A, L-4H
IAP



KOTZEBUE N66°53.14' W162°32.40' NOTAM FILE OTZ.

(H) VORW/DME 115.7 OTZ Chan 104 253° 1.4 NM to Ralph Wien Meml. 121/15E.

NOME
H-1A, L-4H