

CONTINUED FROM PRECEDING PAGE

COMMUNICATIONS: CTAF 122.6

RCO 122.6 (COLD BAY RADIO)

② ANCHORAGE CENTER APP/DEP CON 121.4

RADIO AIDS TO NAVIGATION: NOTAM FILE DUT.

DUTCH HARBOR NDB/DME (HW) 283 DUT Chan 86 N53°54.31' W166°32.87' at fld. 272/9E.

DME portion unusable:

005°-080°

081°-330° byd 13 NM

331°-004° byd 15 NM

COMM/NAV/WEATHER REMARKS: For a toll free call to Cold Bay FSS dial 1-800-478-7250. For a toll free call to Kenai FSS dial 1-866-864-1737. Wx information avbl on 129.5 (call sign Dutch WX) or ph: 907-581-1256, 1645-0345Z†. Cold Bay FSS ops 1700-0300Z†, all otr times Kenai FSS.

UPPER WASILLA LAKE SPB (See WASILLA on page 256)

UTOPIA CREEK N65°59.71' W153°41.63' NOTAM FILE UTO.

FAIRBANKS

NDB/DME (HW) 272 UTO Chan 22(Y) 264° 14.2 NM to Hughes. 983/17E.

L-4I

NDB unusable:

210°-240°

340°-355°

NDB/DME unusable:

45°-105° byd 25 NM

105°-45°

UTQIAGVIK

WILEY POST-WILL ROGERS MEML (BRW)(PABR) 0 SE UTC-9(-8DT) N71°17.09' W156°46.12' POINT BARROW

49 B ARFF Index—See Remarks NOTAM FILE BRW

H-1A, L-4I

RWY 08-26: H7100X150 (ASPH-GRVD) S-75, D-160, 2D-300

IAP

PCR 458 F/C/X/U HIRL

RWY 08: MALSR. PAPI(P4R)—GA 3.0° TCH 51'. RVR-T Thld dsplcd 600'. Rgt tfr.

RWY 26: REIL. PAPI(P4L)—GA 3.0° TCH 50'. RVR-R Thld dsplcd 600'. Antenna.

RUNWAY DECLARED DISTANCE INFORMATION

RWY 08: TORA-7100 TODA-7100 ASDA-6500 LDA-5900

RWY 26: TORA-7100 TODA-7100 ASDA-6500 LDA-5900

SERVICE: S2 FUEL 100LL, JET A1 LGT ACTVT MALSR Rwy 08; REIL Rwy 26—CTAF. HIRL Rwy 08-26 preset low intst—incr intst BRW FSS 1500-0700Z†; aft hr—CTAF. PAPI Rwy 08 & 26 on consly. Rotg bcn on consly.

AIRPORT REMARKS: Attended 1500-0530Z†. Waterfowl invof arpt

Spring-Fall. Class I, ARFF Index B. Clsd to acr ops more than 30 pax seats excp PPR in writing—Airport Manager P. O. Box 367 Barrow, AK 99723. Rcnd lgr acft use elephant ear to turn around. Main ramp txl non std wingtip clnc; rwy back taxi when lgr acft prkd on main ramp.

Snow removal, wildlife ctl, cond rptg & arpt maint svc avbl durg maint duty hr 1500-0530Z†; aft hr—AMGR. Arpt sand lgr gradation than FAA rcmd/see AC150/5200-30. TSA reg arpt; See 49 CFR 1542. Gates & doors must be secured at all times. Tsnt - AMGR or BRW FSS for info. NOTE: See Notices—Drone Activity at Coastal Airport Launch Sites.

FAA rcmd/see AC150/5200-30. TSA reg arpt; See 49 CFR 1542. Gates & doors must be secured at all times. Tsnt - AMGR or BRW FSS for info. NOTE: See Notices—Drone Activity at Coastal Airport Launch Sites.

FAA rcmd/see AC150/5200-30. TSA reg arpt; See 49 CFR 1542. Gates & doors must be secured at all times. Tsnt - AMGR or BRW FSS for info. NOTE: See Notices—Drone Activity at Coastal Airport Launch Sites.

AIRPORT MANAGER: 907-852-5851

WEATHER DATA SOURCES: ASOS 132.150 (907) 931-6017. (WX CAM)

COMMUNICATIONS: CTAF 123.6 AFIS 132.15 (1500-0700Z†; OT ctc Fairbanks FSS)

FSS BRW (BARROW) 1500-0700Z†; OT ctc Fairbanks FSS.

BARROW RADIO 121.5 122.2 122.6 123.6 (LAA 123.6)

ANCHORAGE CENTER APP/DEP CON 135.3

AIRSPACE: CLASS E svc continuous.

RADIO AIDS TO NAVIGATION: NOTAM FILE UTO.

ILS/DME 110.5 I-BRW Chan 42 Rwy 08. Class IE. Localizer backcourse unusable 2.2 DME abv 2,050' and at 1.0 DME abv 1,050'. Autopilot coupled apchs not applicable blw 290' MSL.

COMM/NAV/WEATHER REMARKS: For local call to Barrow FSS call 907-852-2511. For a toll free call to Fairbanks FSS call 1-866-248-6516. WSO 907-852-6484. AFIS operd by BRW FSS when open, OT Fairbanks FSS.

