CONTINUED FROM PRECEDING PAGE

AIRSPACE: CLASS B See VFR Terminal Area Chart.
RADIO AIDS TO NAVIGATION: NOTAM FILE ADW.
ANDREWS (L) (L) VORTACW 113.1 ADW Chan 78 N38°48.43′ W76°51.98′ at fld. 263/10W.
VOR unusable:
035°–045° blo 2,500′
089°–182°
183°–227° blo 4,000′
230°–236° byd 20 NM
237°–270°
333°–048°
TACAN AZIMUTH unusable:
035°–045° blo 2,500′
220°–280°
295°–310°
DME unusable:
035°–045° blo 2,500′
220°–280°
ILS 111.5 I–RWS Rwy 01L. Class IIIE.
ILS 110.5 I–VJM Rwy 01R. Class IE.
ILS 110.5 I–GQZ Rwy 19L. Class IE.
ILS 111.5 I–MXK Rwy 19R. Class IIIE. LOC unusable 25° right of course.

KENTMORR AIRPARK (See STEVENSVILLE on page 113)

LAYTONSVILLE

DAVIS (W5Ø) 3 N UTC–5(–4DT) N39°14.59′ W77°09.05′ **WASHINGTON**
609 TPA—1409(800) NOTAM FILE DCA
RWY 08–26: H2600X50 (ASPH) 0.8% up E
RWY 08: Trees.
RWY 26: Trees.
SERVICE: S2 **FUEL** 100LL
AIRPORT REMARKS: Attended Mon–Fri dawn–dusk. Arpt closed dusk–dawn. Birds and wildlife on and invof arpt. Touch and go ops NA. Rwy 26, pond 80 ft R of thr.
AIRPORT MANAGER: 301-253-2897
COMMUNICATIONS: CTAF/UNICOM 122.8
CLEARANCE DELIVERY PHONE: For CD ctc Potomac Apch at 866-429-5882.
COMM/NAV/WEATHER REMARKS: UNICOM unmon.

LEE (See ANNAPOLIS on page 90)