CONTINUED FROM PRECEDING PAGE

VOR TEST FACILITY (VOT) 111.0
RADIO AIDS TO NAVIGATION: NOTAM FILE JNU.
SISTERS ISLAND (H) (H) VORTACW 114.0 SSR Chan 87 N58°10.66´ W135°15.53´ 043° 24.0 NM to fld. 40/20E.
VOR unusable:
050°–070° byd 12 NM blo 10,000´
115°–130° byd 32 NM blo 8,000´
131°–175° byd 25 NM blo 13,000´
176°–189° byd 35 NM blo 14,000´
190°–245° byd 30 NM blo 12,000´
246°–260° byd 18 NM blo 7,000´
306°–360° byd 21 NM
TAC AZM unusable:
050°–070° byd 12 NM blo 10,000´
115°–130° byd 32 NM blo 8,000´
131°–175° byd 25 NM blo 13,000´
176°–189° byd 28 NM blo 14,000´
190°–245° byd 30 NM blo 12,000´
246°–260° byd 18 NM blo 7,000´
306°–360° byd 21 NM
DME unusable:
050°–070° byd 12 NM blo 10,000´
115°–130° byd 32 NM blo 8,000´
131°–175° byd 25 NM blo 13,000´
176°–189° byd 28 NM blo 14,000´
190°–245° byd 30 NM blo 12,000´
246°–260° byd 18 NM blo 7,000´
306°–360° byd 21 NM
COGHLAN ISLAND NDB (HWZ) 212 CGL N58°21.56´ W134°41.97´ 074° 3.8 NM to fld. 58/20E.
NDB unusable:
325°–050° byd 30 NM
270°–324° byd 35 NM
220°–270° byd 24 NM blo 13,000´
LDA/DME 109.9 I–JDL Chan 36 Rwy 08. LOC unusable byd 30° left of inbound course.
COMM/NAV/WEATHER REMARKS: When ATCT clsd arpt adzy svc – CTAF. For a toll free call to Juneau FSS dial 1–866–297–2236. Juneau FSS – lcl 907–789–7380. Between May and Sep an additional twr freq of 120.7 will be in use. Its use will be announced via the ATIS. All other times use 118.7. Juneau Intl Seaplane Basin contact Juneau Tower on freq 118.7 for taxi, take–off and landing instructions. Waterlane controlled by Juneau Tower. Taxiing acft should taxi clockwise around the outer edge of float pond.

• • • • • • • • • • • • • • • • • •

WATERWAY 08W–26W: 4800X150 (WATER)
SEAPLANE REMARKS: Attended continuously. Wildlife and birds on and in vicinity of seaplane base. Transient public dock SW corner.

KAARUK N67°40.04´ W149°49.50´ **FAIRBANKS**
RCO 122.4 (FAIRBANKS RADIO) **L–4J**

KACHEMAK N59°38.48´ W151°30.02´ NOTAM FILE HOM. **SEWARD**
NDB (HW) 277 ACE at Homer. 17E. **H–1B, 2K, L–1A, 2J, 3D, 4F**